

## C4 Street/Strip Valve Body Instructions

PA26301, PA26302#



1. Drain transmission by removing the black oil pan bolts and work towards the front slowly (if dipstick is attached to the pan, dipstick removal will allow most oil to drain).
2. Remove the eight valve body attaching bolts and remove valve body by pulling straight down.
3. Install transbrake valve body into transmission carefully. You must engage selector lever into manual valve. Note that transmission will now become fully manual and kickdown lever is now unused.
4. Tighten valve body finger tight, remembering that the longer bolts attach the filter to the valve body. Check for free operation of shifter linkage and if acceptable tighten valve body bolts to 80-120 in. lbs.
5. Remove excess gasket material from pan mounting area of the case as well as from the pan itself.
6. Tighten pan bolts to 12-16 ft. lbs.