

## 4.6 Pro Fit Bellhousing

PA26477#



Installation:

This bellhousing comes with bellhousing bolts, C4 spacer ring, and C4 pump bolts. If you are using a Powerglide transmission you must purchase the adapter ring and bolt kit separately. Installing this bellhousing is very simple.

1. Match up the holes in the spacer ring to the front of your C4 transmission. Place the ring on the pump. This ring will give the exact depth needed for the torque converter.

2. Place the bellhousing on to the front of the C4 and with the supplied bolts inserted and torque to 45 ft. lbs. Do not use the factory pump bolts. They are not long enough.

3. The transmission is now ready to be installed on the engine. Original bellhousing bolts can be re-used, but it is not recommended. The two allen bolts with washers are to be used on the dowel pin holes. Re-use original block plate and starter bolts.



Need more help? Call us at 301-963-8078